

INTERNATIONAL TELECOMMUNICATION UNION





SERIES G: TRANSMISSION SYSTEMS AND MEDIA, DIGITAL SYSTEMS AND NETWORKS

Digital terminal equipments – Coding of analogue signals by pulse code modulation

Transmission performance characteristics of pulse code modulation channels

ITU-T Recommendation G.712

## ITU-T G-SERIES RECOMMENDATIONS TRANSMISSION SYSTEMS AND MEDIA, DIGITAL SYSTEMS AND NETWORKS

INTERNATIONAL TELEPHONE CONNECTIONS AND CIRCUITS	G.100-G.199
GENERAL CHARACTERISTICS COMMON TO ALL ANALOGUE CARRIER- TRANSMISSION SYSTEMS	G.200–G.299
INDIVIDUAL CHARACTERISTICS OF INTERNATIONAL CARRIER TELEPHONE SYSTEMS ON METALLIC LINES	G.300–G.399
GENERAL CHARACTERISTICS OF INTERNATIONAL CARRIER TELEPHONE SYSTEMS ON RADIO-RELAY OR SATELLITE LINKS AND INTERCONNECTION WITH METALLIC LINES	G.400–G.449
COORDINATION OF RADIOTELEPHONY AND LINE TELEPHONY	G.450-G.499
TESTING EQUIPMENTS	G.500-G.599
TRANSMISSION MEDIA CHARACTERISTICS	G.600–G.699
DIGITAL TERMINAL EQUIPMENTS	G.700–G.799
General	G.700-G.709
Coding of analogue signals by pulse code modulation	G.710-G.719
Coding of analogue signals by methods other than PCM	G.720–G.729
Principal characteristics of primary multiplex equipment	G.730–G.739
Principal characteristics of second order multiplex equipment	G.740-G.749
Principal characteristics of higher order multiplex equipment	G.750–G.759
Principal characteristics of transcoder and digital multiplication equipment	G.760–G.769
Operations, administration and maintenance features of transmission equipment	G.770–G.779
Principal characteristics of multiplexing equipment for the synchronous digital hierarchy	G.780–G.789
Other terminal equipment	G.790–G.799
DIGITAL NETWORKS	G.800–G.899
DIGITAL SECTIONS AND DIGITAL LINE SYSTEM	G.900-G.999

For further details, please refer to the list of ITU-T Recommendations.

# **ITU-T Recommendation G.712**

## Transmission performance characteristics of pulse code modulation channels

#### **Summary**

This Recommendation deals with the transmission performance characteristics of PCM channels of digital transmission equipment. Requirements to be met between 4-wire and 2-wire analogue ports are given as well as requirements for analogue-to-digital and digital-to-analogue connections. The parameters and values specified in this Recommendation apply to the use of PCM equipment connected to analogue trunks or to analogue and digital exchanges.

#### Source

ITU-T Recommendation G.712 was prepared by ITU-T Study Group 15 (2001-2004) and approved under the WTSA Resolution 1 procedure on 29 November 2001.

i

#### FOREWORD

The International Telecommunication Union (ITU) is the United Nations specialized agency in the field of telecommunications. The ITU Telecommunication Standardization Sector (ITU-T) is a permanent organ of ITU. ITU-T is responsible for studying technical, operating and tariff questions and issuing Recommendations on them with a view to standardizing telecommunications on a worldwide basis.

The World Telecommunication Standardization Assembly (WTSA), which meets every four years, establishes the topics for study by the ITU-T study groups which, in turn, produce Recommendations on these topics.

The approval of ITU-T Recommendations is covered by the procedure laid down in WTSA Resolution 1.

In some areas of information technology which fall within ITU-T's purview, the necessary standards are prepared on a collaborative basis with ISO and IEC.

#### NOTE

In this Recommendation, the expression "Administration" is used for conciseness to indicate both a telecommunication administration and a recognized operating agency.

#### INTELLECTUAL PROPERTY RIGHTS

ITU draws attention to the possibility that the practice or implementation of this Recommendation may involve the use of a claimed Intellectual Property Right. ITU takes no position concerning the evidence, validity or applicability of claimed Intellectual Property Rights, whether asserted by ITU members or others outside of the Recommendation development process.

As of the date of approval of this Recommendation, ITU had not received notice of intellectual property, protected by patents, which may be required to implement this Recommendation. However, implementors are cautioned that this may not represent the latest information and are therefore strongly urged to consult the TSB patent database.

#### © ITU 2002

All rights reserved. No part of this publication may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying and microfilm, without permission in writing from ITU.

# CONTENTS

# Page

0	Scope.								
1	General								
	1.1	Measurement considerations							
	1.2	Port definitions							
	1.3	Abbreviations							
2	Relativ	e levels at analogue ports							
	2.1	Relative levels at 4-wire ports (E4)							
	2.2	Relative levels at 2-wire ports (E2)							
3	Adjust	ment of actual relative levels							
	3.1	Adjustment of the decoding side (T <sub>in</sub> to E <sub>out</sub> )							
	3.2	Adjustment of the encoding side (E <sub>in</sub> to T <sub>out</sub> )							
	3.3	Load capacity (overload point)							
4	Short-	and long-term variation of loss with time							
5	Nomin	Nominal impedance and return loss of analogue ports							
	5.1	Nominal impedance							
	5.2	Return loss							
6	Impeda	ince unbalance about earth							
	6.1	Longitudinal conversion loss							
	6.2	Longitudinal conversion transfer loss							
7	Attenu	ation/frequency distortion							
8	Group	delay							
	8.1	Absolute group delay							
	8.2	Group delay distortion with frequency							
9	Idle ch	annel noise							
	9.1	Weighted noise							
	9.2	Single frequency interference							
10	Discrin	nination against out-of-band signals							
	10.1	Input signals above 4600 Hz at analogue ports E4 and E2							
	10.2	Input signals below 300 Hz at analogue ports E4 and E2							
	10.3	Overall requirement (4-wire only)							
11	Spurio	us signals at the channel output port							
	11.1	Spurious out-of-band signals at the channel output port							
	11.1.1	In-band input signal							

	11.1.2	Overall requirement
	11.2	Spurious in-band signals at the channel output port
12	Total d	istortion, including quantizing distortion
13	Variatio	on of gain with input level
14	Crossta	lk
	14.1	General
	14.2	Interchannel crosstalk, channels between analogue ports
	14.2.1	Far-end crosstalk
	14.2.2	Go-to-return crosstalk for channels between 4-wire analogue ports
	14.3	Interchannel crosstalk, channels between analogue and digital ports
	14.3.1	Far-end and near-end crosstalk measured with analogue test signal
	14.3.2	Go-to-return crosstalk measured with analogue test signal
	14.3.3	Far-end and near-end crosstalk measured with digital test signal
	14.3.4	Go-to-return crosstalk measured with digital test signal
15	Interfer	ence from signalling
	15.1	Channels between 4-wire analogue ports
	15.2	Channels between 2-wire analogue ports
	15.3	Channels between 4-wire analogue and digital ports
	15.4	Channels between 2-wire analogue and digital ports
16	Echo ai	nd stability at 2-wire ports, E2
	16.1	Terminal Balance Return Loss (TBRL)
	16.2	Stability Loss (SL)
Appe	endix I – A	Alternative measurement methods using band limited noise signals
	I.1	Variation of gain with input level
	I.2	Total distortion, including quantizing distortion

# **ITU-T Recommendation G.712<sup>1</sup>**

# Transmission performance characteristics of pulse code modulation channels

## 0 Scope

This Recommendation deals with the transmission performance characteristics of PCM channels transmitted via digital transmission equipment. Requirements to be met between 4-wire and 2-wire analogue ports are given as well as requirements for analogue-to-digital and digital-to-analogue connections.

## 1 General

Performance characteristics which follow should be met between voice-frequency ports or between the voice-frequency and digital ports of PCM channels coded in accordance with ITU-T Rec. G.711.

Equipment which meets the analogue-to-analogue requirements, but not the analogue-to-digital requirements, may only be used as permanently connected pairs of equipment.

The parameters and values specified in this Recommendation apply to the use of PCM equipment connected to analogue trunks or to analogue and digital exchanges. When PCM equipment is connected directly to analogue subscriber lines, different values for some of the parameters may be required. ITU-T Rec. Q.552 contains those values. The requirements in this Recommendation may also be applied if the PCM equipment is directly connected to an analogue local exchange that is virtually transparent with regard to the impedances connected to its ports and the subscriber lines are short (e.g. less than 500 metres).

Line current is not normally to be expected at the ports of the PCM equipment. If "line current" is nevertheless present, as is the case when signalling takes place on the two wires, any noise it contributes should meet requirements at the appropriate interface as described in the Q.550-series of Recommendations. The limits should be met when any signalling function is in the normal speaking condition, but excluding any dynamic signalling conditions, e.g. metering.

## 1.1 Measurement considerations

When a nominal reference frequency of 1020 Hz is indicated (e.g. measurement of attenuation/frequency distortion and adjustment of relative levels), the actual frequency should be 1020 Hz, +2 Hz, -7 Hz in accordance with ITU-T Rec. O.6.

In the following subclauses, the concepts of a "standard digital generator" and "a standard digital analyser" should be assumed and these are defined as follows.

A **standard digital generator** is a hypothetical device which is absolutely ideal, i.e. a perfect analogue-to-digital converter preceded by an ideal low pass filter (assumed to have no attenuation/frequency distortion and no group delay distortion), and which may be simulated by a digital processor.

A **standard digital analyser** is a hypothetical device which is absolutely ideal, i.e. a perfect digital-to-analogue converter followed by an ideal low pass filter (assumed to have no attenuation/frequency distortion and no group delay distortion), and which may be simulated by a digital processor.

<sup>&</sup>lt;sup>1</sup> This Recommendation replaces ITU-T Recs. G.712, G.713, G.714 and G.715 of the CCITT *Blue Book* Volume III, Fascicle III.4.

ITU-T Rec. O.133 contains information about test equipment based on these concepts. Account should be taken of the measurement accuracy provided by test equipment designed in accordance with that Recommendation.

A PCM quiet signal is defined to be an idle character signal corresponding to decoder output value number 0 for  $\mu$ -law or decoder output value number 1 for A-law with the sign bit in a fixed state.

The following specifications are based on ideal measuring equipment. Therefore, they do not include any margin for measurement errors.

## **1.2** Port definitions

The term "port" in this Recommendation is defined as a functional unit (e.g. a connector) of the PCM equipment through which signals can enter or leave the unit under test. The measurements are made at the equipment, and the requirements do not include an allowance for wiring to a distribution frame.

Figure 1 shows two elements of PCM equipment connected via a digital cross-connect (DXC) system. Each element of PCM equipment is shown to have a 4-wire analogue voice-frequency port, E4, and a 2-wire analogue voice-frequency port, E2. Each of the PCM elements is connected to the DXC by digital ports A or B (ports A and B are defined in 1.1/Q.551), which consists of transparent 64 kbit/s PCM channels within a higher order digital signal conforming to applicable Recommendations. The DXC implements transparent 64 kbit/s cross connections between its own A or B ports, or to the digital test point, T. The T point consists of a 64 kbit/s channel within a digital signal suitable for connection to the standard digital generator and analyser. Since the connections provided by the DXC are 64 kbit/s transparent, the paths within the DXC are assumed not to affect the recommended transmission performance characteristics except for absolute delay. The test points T are defined for specification purposes. They may not physically exist in a DXC but may be accessed via the DXC network.

Unless stated otherwise, measurements between two-wire ports ( $E2_{1in}$  to  $E2_{2out}$  connections) should be made with the 4-wire loop opened in such a way that the impedances presented to the 4-wire port of the 2-wire/4-wire terminating unit are representative of those that will occur in normal operation. This condition may be achieved by interrupting the digital signal in the opposite direction to the direction of measurement and injecting a PCM quiet signal into the appropriate channel. It should be noted that the opening of the 4-wire loop is considered necessary to determine the intrinsic performance of the equipment. In normal operation, where the loop is not opened, the impact on overall performance of the terminating impedances connected to the 2-wire ports needs to be taken into account.

Figure 1 is similar to Figure 1/Q.551, which identifies interfaces, transmission levels designations and test points at a digital exchange.

The performance characteristics between ports were previously specified in CCITT *Blue Book*, Volume III, Fascicle III.4, as shown in the Table 1.



NOTE – Numbers 1 or 2 in the subscript indicate multiplexers 1 or 2.

Figure 1/G.712 – PCM equipment and test ports

#### Table 1/G.712 – Equivalence between previous ITU-T Recommendations and channels specified in this Recommendation

Channel	Previous ITU-T Recommendation
4-wire analogue to 4-wire analogue (E4 $_1$ to E4 $_2$ channels)	G.712
2-wire analogue to 2-wire analogue (E2 <sub>1</sub> to E2 <sub>2</sub> channels)	G.713
4-wire analogue-to-digital (E4 to A or B for a primary multiplexer)	G.714
2-wire analogue-to-digital (E2 to A or B for a primary multiplexer)	G.715

## 1.3 Abbreviations

This Recommendation uses the following abbreviations:

- DXC Digital Cross-Connect
- FDM Frequency Division Multiplex
- FEXT Far-End crosstalk
- NEXT Near-End crosstalk
- PCM Pulse Code Modulation
- SL Stability Loss
- TBRL Terminal Balance Return Loss

## 2 Relative levels at analogue ports

## 2.1 Relative levels at 4-wire ports (E4)

When attenuation pads are set to zero loss,  $L_o$  at  $E4_{2out}$  and  $L_i$  at  $E4_{1in}$  must have one of the following two series of nominal values: Maximum  $L_o = +4$  dBr and minimum  $L_i = -14$  dBr; or maximum  $L_o = +7$  dBr and minimum  $L_i = -16$  dBr. See 11/G.232.

# 2.2 Relative levels at 2-wire ports (E2)

Due to differences in network transmission plans and equipment utilization, network operators have differing requirements for the range of relative levels to be provided. The following ranges would encompass the requirements of a large number of network operators:

- input level ( $L_i$ ) at encoding side 0 to -5 dBr in 0.5 dB steps;
- output level ( $L_0$ ) at decoding side -2 to -7.5 dBr in 0.5 dB steps.

It is recognized that it is not necessarily appropriate for a specifically designed piece of equipment to be capable of operating over the entire range.

NOTE – The requirements in this clause are different from the requirements in 2.1.3/Q.552.

# **3** Adjustment of actual relative levels

## 3.1 Adjustment of the decoding side (T<sub>in</sub> to E<sub>out</sub>)

The gain of the decoding side should be adjusted by connecting  $T_{in}$  to a standard digital generator and applying a 1020 Hz sinusoidal test signal at a level of 0 dBm0. The adjustment should result in an output level of 0 dBm0  $\pm$  0.3 dB for 4-wire ports ( $T_{in}$  to E4<sub>out</sub>) or an output level of 0 dBm0  $\pm$  0.4 dB for 2-wire ports ( $T_{in}$  to E2<sub>out</sub>) and should be made under typical conditions of power supply voltage, humidity and temperature.

# 3.2 Adjustment of the encoding side (E<sub>in</sub> to T<sub>out</sub>)

The gain of the encoding side should be adjusted by connecting  $T_{out}$  to a standard digital analyser and applying a 1020 Hz test signal at a level of 0 dBm0 to  $E_{in}$ . The adjustment should result in an output level of 0 dBm0 ± 0.3 dB for 4-wire ports (E4<sub>in</sub> to  $T_{out}$ ) or an output level of 0 dBm0 ± 0.4 dB for 2-wire ports (E2<sub>in</sub> to  $T_{out}$ ) and should be made under typical conditions of power supply voltage, humidity and temperature.

## 3.3 Load capacity (overload point)

The load capacity of the encoding side may be checked by applying a 1020 Hz sinusoidal test signal at  $E_{in}$ . The level of this signal should be initially well below the maximum value of  $T_{out}$  (= $T_{outmax}$ ), and should then be slowly increased. The input level should be measured at which the first occurrence of the character signal corresponding to the extreme quantizing interval for both positive and negative values is observed.  $T_{outmax}$  is taken as being 0.3 dB greater than the measured input level.

This method allows  $T_{outmax}$  to be checked for both positive and negative amplitudes, and the values thus obtained should be within 0.4 dB of the theoretical load capacity (i.e. +3.14 dBm0 for the A-law or +3.17 dBm0 for the  $\mu$ -law).

## 4 Short- and long-term variation of loss with time

When a 1020 Hz sinusoidal test signal at a level of -10 dBm0 (preferred value; however, a level of 0 dBm0 may be used) is applied to any voice-frequency input, the level measured at the corresponding output should not vary by more than the limits shown in Table 2 during any 10-minute interval of typical operation, nor by more than the limits shown during any one year under the permitted variations in the power supply voltage and temperature.

	Maximum permit		
Channels	10-minute interval	One-year interval	
4-wire to 4-wire (E4 <sub>1in</sub> to E4 <sub>2out</sub> )	$\pm 0.2$	± 0.5	
2-wire to 2-wire (E2 <sub>1in</sub> to E2 <sub>2out</sub> )	$\pm 0.2$	± 0.6	
4-wire to digital (E4 <sub>in</sub> to T <sub>out</sub> )	$\pm 0.1$	± 0.3	
Digital to 4-wire (Tin to E4out)	$\pm 0.1$	± 0.3	(Note)
2-wire to digital (E2 <sub>in</sub> to T <sub>out</sub> )	$\pm 0.1$	± 0.3	
Digital to 2-wire (T <sub>in</sub> to E2 <sub>out</sub> )	$\pm 0.1$	± 0.3	(Note)
NOTE – The 0 dBm0 sequence of Tables 5/	G.711 or 6/G.711 may be	e used.	

## Table 2/G.712 – Requirements for short- and long-term variation of level with time

## 5 Nominal impedance and return loss of analogue ports

## 5.1 Nominal impedance

The nominal impedance at the 4-wire analogue input and output ports,  $E4_{in}$  and  $E4_{out}$ , should be 600  $\Omega$ , balanced.

For 2-wire analogue ports, E2, no single value of impedance is recommended. The following values can be found in practice:

- $600 \Omega$  resistive, balanced;
- 900  $\Omega$  resistive, balanced;
- $600 \Omega + 2.16 \mu F$ , balanced;
- 900  $\Omega$  + 2.16  $\mu$ F, balanced.
- 750 Ω //150 nF + 270 Ω

NOTE 1 – Some examples of complex impedances used in connection with subscriber lines can be found in Table 1/Q.552.

NOTE 2 – Measurements at ports with complex impedances shall follow the definitions and conventions given in Annex A/G.100.

## 5.2 Return loss

The return loss, against the nominal impedance, should meet the return loss requirements shown in Table 3 over the frequency range 300 Hz to 3400 Hz.

	Return loss (dB)		
Analogue port	300 Hz to 600 Hz	600 Hz to 3400 Hz	Notes
4-wire, E4	>20	>20	1
2-wire, E2	>12	>15	2
NOTE 1 – The return loss li Figure 5/G 232)	mit should be met when the ac	ljusting pads are set to 0 dB (se	e

NOTE 2 – Reflections due to impedance mismatches at 2-wire/4-wire ports may cause severe sidetone and echo problems in the network. Network operators need to adopt a suitable impedance strategy, including tolerances, to ensure an adequate transmission quality. (For further information, see clause 5/G.121.)

# 6 Impedance unbalance about earth

The longitudinal conversion loss parameters referred to below are defined in ITU-T Rec. 0.9, which also gives some information about the requirements of test circuits (see Note 1 of Table 4). The value of Z in the driving test circuit should be within  $\pm 20\%$  of the values shown in Tables 4 and 5. The termination at the other port shall be the nominal impedance.

## 6.1 Longitudinal conversion loss

The longitudinal conversion loss (see 4.1/O.9) should not be less than the limits in Table 4.

	Z	Longitudinal conversion loss (dB)				
Port	(Ω)	300 Hz to 600 Hz	600 Hz to 2400 Hz	2400 Hz to 3400 Hz	Notes	
4-wire, E4 <sub>in</sub>	600	>46	>46	>41	1, 2	
4-wire, E4 <sub>out</sub>	600	>46	>46	>41	1, 2	
2-wire, E2	600	>40	>46	>41	1, 2, 3, 4	
2-wire, E2	750	>40	>46	>41	1, 2, 3, 4	

 Table 4/G.712 – Longitudinal conversion loss requirements for E4 and E2 ports

NOTE 1 – Attention is drawn to clause 5/O.9, which shows the equivalence between a number of different test driving circuits and also includes information concerning the inherent balance requirements of the test bridge.

NOTE 2 – Attention is drawn to the fact that these values represent minimum requirements. The magnitude of potential longitudinal signal voltages depends, for example, on system use, the system environment, the location of hybrid transformers and attenuators, and may therefore vary for different network operators. Some network operators have found it necessary to specify higher values for longitudinal conversion loss and longitudinal conversion transfer loss to ensure that transverse voltages caused by possible longitudinal signal voltages are sufficiently small.

NOTE 3 – For frequencies below 300 Hz, in particular at 50 Hz or 60 Hz, overall rejection of longitudinal interference can be achieved by a combination of good longitudinal balancing and high pass filtering (see 10.2).

NOTE 4 – The measurements should be made selectively.

# 6.2 Longitudinal conversion transfer loss

The difference between the longitudinal conversion transfer loss (see 4.3/O.9) at the specified frequencies and the insertion loss at the same frequencies should not be less than the limits in Table 5 as specified from input to output ports. The requirements are applicable with the switch S (see Figure 3/O.9) closed.

Table 5/G.712 – Longitudinal conversion transfer loss requirements	
for channels between analogue ports	

Channel	Z		en the longitudinal of and the insertion los	conversion transfer ss (dB)	Notes
	(Ω)	300 Hz to 600 Hz	600 Hz to 2400 Hz	2400 Hz to 3400 Hz	
4-wire, E4 <sub>1in</sub> to E4 <sub>2out</sub>	600	>46	>46	>41	1, 2
2-wire, E2 <sub>1in</sub> to E2 <sub>2out</sub>	600	>40	>46	>41	1, 2, 3, 4
NOTE – See Notes to Table 4.					

## 7 Attenuation/frequency distortion

The variations with frequency of the attenuation of any channel should lie within the limits shown in the masks of Figures 2, 3, 4 or 5.

The nominal reference frequency is 1020 Hz.

The preferred input power level is -10 dBm0, in accordance with ITU-T Rec. O.6. As an alternative, a level of 0 dBm0 may be used. The attenuation/frequency distortion is the logarithmic ratio of output voltage at the reference frequency (nominally 1020 Hz), U(1020 Hz), divided by its value at frequency *f*, U(f):

Attenuation/frequency distortion = 
$$20 \log \frac{U(1020 \text{ Hz})}{U(f)}$$
.

The formula also applies when complex nominal impedances are used at 2-wire ports



NOTE - In some applications in which several PCM channels may be connected in tandem, it may be necessary to extend the +0.5 dB limit from 2400 Hz to 3000 Hz.





NOTE – Some Administrations apply a limit of 1 dB maximum loss for the frequency range 300 Hz to 3000 Hz.

Figure 3/G.712 – Attenuation/frequency distortion for channels between 2-wire analogue ports (E2<sub>1in</sub> to E2<sub>2out</sub>)



NOTE - In some applications in which several PCM channels may be connected in tandem, it may be necessary to extend the +0.25 dB limit from 2400 Hz to 3000 Hz.





 $\rm NOTE$  – Some Administrations apply a limit of 0.5 dB maximum loss for the frequency range 300 Hz to 3000 Hz.

# Figure 5/G.712 – Attenuation/frequency distortion for channels between a 2-wire analogue port and a digital port (E2<sub>in</sub> to T<sub>out</sub> and T<sub>in</sub> to E2<sub>out</sub>)

## 8 Group delay

Specifications of absolute group delay and group delay distortion between analogue and digital ports are design objectives only.

The requirements on absolute group delay and group delay distortion should be met at an input power level of -10 dBm0 (preferred value). As an alternative, a level of 0 dBm0 may be used.

## 8.1 Absolute group delay

The absolute group delay at the frequency of minimum group delay should not exceed the limit in Table 6.

Note that absolute delay is specified to the A or B port, since the digital cross-connect system will contribute with additional delay. These are design objectives only.

Channels	Absolute group delay (µs)
4-wire analogue-to-analogue channel (E4 <sub>1in</sub> to E4 <sub>2out</sub> )	< 600
2-wire analogue-to-analogue (E2 <sub>1in</sub> to E2 <sub>2out</sub> )	< 750
4-wire analogue-to-digital (E4in to Aout or Bout)	< 360
Digital to 4-wire analogue (Ain or Bin to E4out)	< 240
2-wire analogue-to-digital (E2in to Aout or Bout)	< 450
Digital to 2-wire analogue (Ain or Bin to E2out)	< 300

 Table 6/G.712 – Requirements for absolute group delay

## 8.2 Group delay distortion with frequency

The group delay distortion should lie within the limits shown in the mask of Figures 6, 7, 8, or 9. The minimum value of absolute group delay is taken as the reference for the group delay distortion.



Figure 6/G.712 – Group delay distortion with frequency for channels between 4-wire analogue ports (E4<sub>1in</sub> to E4<sub>2out</sub>)



Figure 7/G.712 – Group delay distortion with frequency for channels between 2-wire analogue ports (E2<sub>1in</sub> to E2<sub>2out</sub>)



Figure 8/G.712 – Group delay distortion with frequency for channels between a 4-wire analogue port and a digital port (E4<sub>in</sub> to T<sub>out</sub> and T<sub>in</sub> to E4<sub>out</sub>)



Figure 9/G.712 – Group delay distortion with frequency for channels between a 2-wire analogue port and a digital port (E2<sub>in</sub> to T<sub>out</sub> and T<sub>in</sub> to E2<sub>out</sub>)

#### 9 Idle channel noise

#### 9.1 Weighted noise

With the input and output ports of the channel terminated in the nominal impedance, the idle channel noise should not exceed the limits of Table 7.

Port terminated	Port measured	Weighted noise (dBm0p)	Notes
4-wire analogue, E4 <sub>1in</sub>	4-wire analogue, E4 <sub>2out</sub>	<-65	
2-wire analogue, E2 <sub>1in</sub>	2-wire analogue, E2 <sub>2out</sub>	<-65	1, 4
4-wire analogue, E4 <sub>in</sub>	Digital, T <sub>out</sub>	<-67	2
Digital, T <sub>in</sub>	4-wire analogue, E4 <sub>out</sub>	<-70	3
2-wire analogue, E2 <sub>in</sub>	Digital, T <sub>out</sub>	<-67	2
Digital, T <sub>in</sub>	2-wire analogue, E2 <sub>out</sub>	<-70	3, 5

Table 7/G.712 – Requirements for weighted idle channel noise

NOTE 1 - This limit does not include any allowance for additional noise which might be present when signalling takes place on the two wires. Due to the effects of quantization, it is not necessarily the case that noise powers can be added.

NOTE 2 – Weighted noise measured at the encoding side.

NOTE 3 – Noise measured at the decoding side. The digital port is driven by a PCM signal (quiet code) corresponding to the decoder output value number 0 for the  $\mu$ -law or decoder output value number 1 for the A-law.

NOTE  $4 - \text{If } L_0 < 5 \text{ dBr}$ , the noise limit is -64 dBm0p.

NOTE 5 – If  $L_0 < -5$  dBr, the noise limit is -75 dBmp.

NOTE 6 – Psophometric measurements of composite signals at ports with complex impedances should be performed with a psophometer having an input impedance equal to the nominal complex impedance specified for that port. The psophometer has to be calibrated accordingly (see also ITU-T Rec. O.41 and Annex A/G.100).

## 9.2 Single frequency interference

The level of any single frequency measured selectively (in particular the sampling frequency and its multiples at the 4-wire analogue,  $E4_{out}$ , and 2-wire analogue,  $E2_{out}$  ports) should not exceed -50 dBm0. Between 300 Hz and 3400 Hz, the level of any single frequency measured selectively and corrected by the psophometric weighting factor (see Table 1/O.41) should not exceed -73 dBm0.

## 10 Discrimination against out-of-band signals

## 10.1 Input signals above 4600 Hz at analogue ports E4 and E2

With any sine-wave signal in the range from 4600 Hz to 72 kHz applied to the input analogue port of the channel at a suitable level, the level of any image frequency produced at an output E or T port should, as a minimum requirement, be at least 25 dB below the level of the test signal.

NOTE – It has been found that a suitable test level is –25 dBm0.

## 10.2 Input signals below 300 Hz at analogue ports E4 and E2

No particular value is recommended.

NOTE 1 – While some network operators have no particular requirement in this respect, some other network operators have found it necessary to provide at least 20 to 26 dB rejection at the encoding side at frequencies across the band 15 Hz to 60 Hz.

NOTE 2 – Overall rejection of longitudinal interference can be achieved by a combination of good longitudinal balancing (see clause 6) and high pass filtering.

## **10.3 Overall requirement (4-wire only)**

Under the most adverse conditions encountered in a national network, the 4-wire PCM channel ( $E4_{in}$  to  $E4_{out}$  or  $E4_{in}$  to  $T_{out}$ ) should not contribute more than 100 pW0p of additional noise in the band 10 Hz to 4 kHz at the channel output, as a result of the presence of out-of-band signals at the 4-wire analogue channel input.

NOTE 1 – The discrimination required depends on the performance of Frequency Division Multiplex (FDM) channel equipment elements and telephone instruments in national networks, and individual network operators should carefully consider the requirements they should specify, taking into account the comments above and the requirement of 10.1 above. In all cases, at least the minimum requirement of 10.1 should be met.

NOTE 2 – Attention is drawn to the importance of the attenuation characteristic in the range 3400 Hz to 4600 Hz. Although other attenuation characteristics can satisfy the following requirements, the filter template of Figure 10 gives adequate protection against the out-of-band signals at 4-wire and 2-wire analogue channel inputs.



NOTE – The curved portion of the graph conforms to the equation:

 $G = 12.5 \left[ \sin \frac{\pi (f - 400)}{1200} - 1 \right] dB$  for the range  $3400 \le f \le 4600$ .

Figure 10/G.712 – Gain relative to gain at 1020 Hz

## 11 Spurious signals at the channel output port

## 11.1 Spurious out-of-band signals at the channel output port

#### 11.1.1 In-band input signal

With any sine-wave test signal in the frequency range 300 Hz to 3400 Hz and at a level of 0 dBm0 applied to the digital or analogue input port of a channel ( $T_{in}$  or a connected E4<sub>in</sub> or E2<sub>in</sub>), the level of spurious out-of-band image signals measured selectively at the 4-wire or 2-wire analogue output port (E4<sub>out</sub> or E2<sub>out</sub>) should be lower than -25 dBm0.

NOTE – Attention is drawn to the importance of the attenuation characteristic in the range 3400 Hz to 4600 Hz. Although other attenuation characteristics can satisfy the above requirement, the filter template of Figure 10 gives adequate protection against the out-of-band signal.

## 11.1.2 Overall requirement

The spurious out-of-band signals should not give rise to unacceptable interference in equipment connected to the PCM channel. In particular, the intelligible or unintelligible crosstalk in a connected FDM channel should not exceed a level of -65 dBm0 as a consequence of the spurious out-of-band signals at the PCM channel output.

NOTE – The discrimination required depends on the performance of FDM channel equipment and telephone instruments in national networks and individual network operators should carefully consider the requirements they should specify, taking into account the comments above and the requirement of 11.1.1 above. In all cases, at least the minimum requirement of 11.1.1 should be met.

#### 11.2 Spurious in-band signals at the channel output port

With any sine-wave test signal in the frequency range 700 Hz to 1100 Hz and at a level of 0 dBm0 applied to the analogue input port of a channel ( $E4_{1in}$  or  $E2_{1in}$ ), the output level at any frequency

other than the frequency of the test signal, measured selectively in the frequency band 300 Hz to 3400 Hz at the 4-wire or 2-wire analogue output port ( $E4_{2out}$  or  $E2_{2out}$ ), should be less than -40 dBm0.

#### 12 Total distortion, including quantizing distortion

With a sine-wave test signal at the nominal reference frequency of 1020 Hz applied to the input port of a channel, the ratio of signal-to-total distortion power measured with the proper noise weighting (see Table 4/G.223) at the output port of the channel should lie above the limits shown in Figures 11 and 12.

NOTE - A method based on a noise test signal is in use. This method, which is described in Appendix I, is not exactly equivalent to the sine-wave test method.



Figure 11/G.712 – Signal-to-total distortion ratio as a function of input level for channels between analogue ports (E4<sub>1in</sub> to E4<sub>2out</sub> and E2<sub>1in</sub> to E2<sub>2out</sub>)



Figure 12/G.712 – Signal-to-total distortion ratio as a function of input level for channels between an analogue port and a digital port (E4<sub>in</sub> to T<sub>out</sub>, T<sub>in</sub> to E4<sub>out</sub>, E2<sub>in</sub> to T<sub>out</sub> and T<sub>in</sub> to E2<sub>out</sub>)

## 13 Variation of gain with input level

With a sine-wave test signal at the nominal reference frequency of 1020 Hz applied to the input port of a channel at a level between -55 dBm0 and +3 dBm0, the gain variation at the output port of the channel relative to the gain at an input level of -10 dBm0, should be within the limits of Figures 13 or 14.

NOTE – A method based on a noise test signal is in use. This method, which is described in Appendix I, is not exactly equivalent to the sine-wave test method.



Figure 13/G.712 – Variation of gain with input level for channels between analogue ports (E4<sub>1in</sub> to E4<sub>2out</sub> and E2<sub>1in</sub> to E2<sub>2out</sub>)



Figure 14/G.712 – Variation of gain with input level for channels between an analogue port and a digital port (E4<sub>in</sub> to T<sub>out</sub>, T<sub>in</sub> to E4<sub>out</sub>, E2<sub>in</sub> to T<sub>out</sub> and T<sub>in</sub> to E2<sub>out</sub>)

#### 14 Crosstalk

#### 14.1 General

For the crosstalk measurements, auxiliary signals are injected as indicated in Figures 15 to 21. These signals are:

- the quiet code, i.e. a PCM signal corresponding to decoder output value number 0 (μ-law) or output value number 1 (A-law) (with the sign bit in a fixed state);
- a low level activating signal, a sine-wave at a level in the range -33 dBm0 to -40 dBm0.
   Care must be taken in the choice of frequency and the filtering characteristics of the measuring apparatus in order that the activating signal does not significantly affect the accuracy of the crosstalk measurement.

#### 14.2 Interchannel crosstalk, channels between analogue ports

#### 14.2.1 Far-end crosstalk

The crosstalk between individual channels should be such that with a sine-wave signal at the nominal reference frequency of 1020 Hz and at a level of 0 dBm0 applied to a 4-wire or 2-wire analogue input port ( $E4_{1in}$  or  $E2_{1in}$ ), the crosstalk level received at the 4-wire or 2-wire analogue output port of any other channel ( $E4_{2out}$  or  $E2_{2out}$ ) should not exceed -65 dBm0 Far-End crosstalk (FEXT). See Figure 15 for measurements of 4-wire and 2-wire channels.

#### 14.2.2 Go-to-return crosstalk for channels between 4-wire analogue ports

The crosstalk between a channel and its associated return channel should be such that with a sine-wave signal at any frequency in the range 300 Hz to 3400 Hz and at a level of 0 dBm0 applied to a 4-wire analogue input port  $E4_{1in}$  or  $E4_{2in}$ , the crosstalk level measured at the 4-wire analogue output port  $E4_{1out}$  or  $E4_{2out}$  respectively of the corresponding return channel should not exceed -60 dBm0 when the channel is connected through to another primary multiplexer. See Figure 15.



Figure 15/G.712 – Measurement of interchannel crosstalk

#### 14.3 Interchannel crosstalk, channels between analogue and digital ports

#### 14.3.1 Far-end and near-end crosstalk measured with analogue test signal

The crosstalk between individual channels should be such that with a sine-wave signal at the nominal reference frequency of 1020 Hz and at a level of 0 dBm0 applied to an analogue input port, the crosstalk level produced in any other channel should not exceed -73 dBm0 for Near-End crosstalk (NEXT) and -70 dBm0 for Far-End crosstalk (FEXT). See Figures 16 and 17 for measurements of 4-wire and 2-wire channels respectively.



Figure 16/G.712 – FEXT and NEXT measurements with analogue test signal for channels with 4-wire (E4) ports



Figure 17/G.712 – FEXT and NEXT measurements with analogue test signal for channels with 2-wire (E2) ports

#### 14.3.2 Go-to-return crosstalk measured with analogue test signal

The crosstalk between a channel and its associated return channel should be such that with a sinewave signal at any frequency in the range 300 Hz to 3400 Hz and at a level of 0 dBm0 applied to an input port, the crosstalk level measured at the output of the corresponding return channel should not exceed –66 dBm0. See Figure 18.



Figure 18/G.712 – Go-to-return crosstalk measurements on 4-wire (E4) ports with analogue test signal

#### 14.3.3 Far-end and near-end crosstalk measured with digital test signal

The crosstalk between individual channels should be such that with a digitally simulated sine-wave signal at the nominal reference frequency of 1020 Hz and at a level of 0 dBm0 applied to the digital input, the crosstalk level received in any other channel should not exceed -70 dBm0 for Near-End crosstalk (NEXT) and for Far-End crosstalk (FEXT). See Figures 19 and 20 for measurements of 4-wire and 2-wire channels respectively.



Figure 19/G.712 – FEXT and NEXT measurements with digital test signal for channels with 4-wire (E4) ports



Figure 20/G.712 – FEXT and NEXT measurements with digital test signal for channels with 2-wire (E2) ports

#### 14.3.4 Go-to-return crosstalk measured with digital test signal

The crosstalk between a channel and its associated return channel should be such that with a digitally simulated sine-wave signal at any frequency in the range 300 Hz to 3400 Hz and at a level of 0 dBm0 applied to a digital input port, the crosstalk level measured at the digital output of the corresponding return channel should not exceed –66 dBm0. See Figure 21.



Figure 21/G.712 – Go-to-return crosstalk measurement with digital test signal

#### **15** Interference from signalling

#### 15.1 Channels between 4-wire analogue ports

The maximum level of any interference into a channel should not exceed -60 dBm0p when signalling (10 Hz signal with a 50/50 duty ratio to simulate pulse dialling) is active simultaneously on all other channels.

#### 15.2 Channels between 2-wire analogue ports

The maximum level of any interference into a channel should not exceed -50 dBm0p when signalling (10 Hz signal with a 50/50 duty ratio to simulate pulse dialling) is active simultaneously on all other channels.

#### 15.3 Channels between 4-wire analogue and digital ports

The characterization of such interference by separate measurements requires four different types of measurement for crosstalk (see Figure 22). In each case, the maximum level of interference in one channel should not exceed –63 dBm0p when signalling (10 Hz signal with a 50/50 duty ratio to simulate pulse dialling) is active simultaneously on all other channels.



Figure 22/G.712 – Measurement of signalling interference contributions

#### 15.4 Channels between 2-wire analogue and digital ports

The characterization of such interference by separate measurements requires two different types of measurement for crosstalk [(see Figure 22, configurations **a**) and **b**)]. In each case, the maximum level of interference in one channel should not exceed -53 dBm0p when signalling (10 Hz signal with a 50/50 duty ratio to simulate pulse dialling) is active simultaneously on all other channels.

#### 16 Echo and stability at 2-wire ports, E2

#### 16.1 Terminal Balance Return Loss (TBRL)

This quantity characterizes the equipment performance required to comply with the network performance objective of ITU-T Rec. G.122 in respect of echo. The Terminal Balance Return Loss (TBRL) is defined as the balance return loss (see definition in 3.1.8.1/Q.552) measured against a balance test network. It is related to the loss between the digital test input point, T<sub>in</sub> and the digital test output point, T<sub>out</sub> (see Figure 23) as follows:

$$a_{io} = T_{in}$$
 to  $T_{out} loss = P_i + P_o + TBRL$  (dB)

where  $P_i$  and  $P_o$  are the measured values of loss in the equivalent circuit of Figure 23 which represent all loss between the digital test point and the 2-wire point, or conversely, at the measurement frequency.

The TBRL should be measured in the arrangement of Figure 23 with a sinusoidal test signal at frequencies across the telephone band covering the bandwidth 300 Hz to 3400 Hz.



Figure 23/G.712 – Arrangement for measuring half-loop loss

Values for the nominal balance impedance and for the maximum deviation of this impedance from the nominal value differ from one network operator to another. The range of impedances presented at the 2-wire port during normal operation also varies considerably. Network operators will need to establish their own requirements for TBRL, taking into account national or international transmission plans. As a minimum requirement, the TBRL limits in Figure 24 should be met when the 2-wire port is terminated with a balance test network which is representative of the impedance conditions expected in the speaking condition from a population of 2-wire trunks connected to the PCM equipment. The limits are provisional.



Figure 24/G.712 – Minimum values of terminal balance return loss (provisional)

#### 16.2 Stability Loss (SL)

The Stability Loss (SL) is defined as the minimum value of the loss  $a_{io}$  measured in the arrangement of Figure 23. The stability loss should be measured between  $T_{in}$  and  $T_{out}$  by terminating the 2-wire port with stability test networks representing the worst case terminating condition encountered in normal operation. Some network operators may find that open circuit and short circuit terminations are sufficiently representative of worst-case conditions. Other network operators may need to specify, for example, an inductive termination to represent that worst-case condition.

The stability loss at any frequency can be expressed as follows:

$$SL \ge P_i + P_o - X$$
 (dB)

where  $P_i$  and  $P_o$  are measured values of loss, at the measurement frequency, under normal terminating conditions at the 2-wire port. *X* has a value dependent on the interaction between the 2-wire input impedance, the 2-wire balance impedance and the impedance actually applied at the 2-wire port. *X* can be computed or measured by the method described in ITU-T Rec. Q.552.

The 2-wire input and balance impedances at a 2-wire/4-wire port usually have to be optimized by network operators with regard to echo and sidetone. The worst-case terminations depend on the actual network conditions. Thus, the value of X is fully determined by network conditions and the impedance strategy. Values between 0 and 3 dB have been observed in practice.

Network operators should choose the nominal values of  $P_i$  and  $P_o$  taking into account the value of X for their particular operating conditions and of national and international transmission plans for overall network stability (see ITU-T Rec. G.122).

#### APPENDIX I

#### Alternative measurement methods using band limited noise signals

#### I.1 Variation of gain with input level

With a band-limited noise signal, as defined in ITU-T Rec. O.131, applied to the input port of any channel at a level between -55 dBm0 and -10 dBm0, the gain variation of that channel, relative to the gain at an input level of -10 dBm0, should be within the limits of Figure I.1 or Figure I.2. The measurement should be limited to the frequency band 350 Hz to 550 Hz in accordance with the filter characteristic defined in 3.2.1/O.131.



Figure I.1/G.712 – Variation of gain with input level for channels between analogue ports (E4<sub>1in</sub> to E4<sub>2out</sub> and E2<sub>1in</sub> to E2<sub>2out</sub>)



Figure I.2/G.712 – Variation of gain with input level for channels between an analogue port and a digital port (E4<sub>in</sub> to T<sub>out</sub>, T<sub>in</sub> to E4<sub>out</sub>, E2<sub>in</sub> to T<sub>out</sub>, and T<sub>in</sub> to E2<sub>out</sub>)

Furthermore, with a sine-wave signal at the nominal frequency of 1020 Hz applied to the input port of any channel at a level between -10 dBm0 and +3 dBm0, the gain variation of that channel, relative to the gain at an input level of -10 dBm0, should be within the limits of Figure I.3 or Figure I.4.



Figure I.3/G.712 – Variation of gain with input level for channels between analogue ports (E4<sub>1in</sub> to E4<sub>2out</sub> and E2<sub>1in</sub> to E2<sub>2out</sub>)



Figure I.4/G.712 – Variation of gain with input level for channels between an analogue port and a digital port (E4<sub>in</sub> to T<sub>out</sub>, T<sub>in</sub> to E4<sub>out</sub>, E2<sub>in</sub> to T<sub>out</sub>, and T<sub>in</sub> to E2<sub>out</sub>)

#### I.2 Total distortion, including quantizing distortion

NOTE – Compared with the sine-wave test method recommended in clause 12, the noise test method here gives fairly smooth curves, not very dependent upon input signal level. The sine-wave method can be more sensitive in identifying possible codec imperfections. Thus, this method responds to practical codec impairments in slightly different ways. The noise test method is about 1.5 dB more stringent than the sine-wave test method.

With a noise signal corresponding to ITU-T Rec. O.131 applied to the input port of a channel, the ratio of signal-to-total distortion power should lie above the limits shown in Figures I.5 through I.10.



Figure I.5/G.712 – Signal-to-total distortion ratio as a function of input level for channels between 4-wire analogue ports (E4<sub>1in</sub> to E4<sub>2out</sub>)



Figure I.6/G.712 – Signal-to-total distortion ratio as a function of input level for channels between 2-wire analogue ports (E2<sub>1in</sub> to E2<sub>2out</sub>)



Figure I.7/G.712 – Signal-to-total distortion ratio as a function of input level for channels between a 4-wire analogue port and a digital port (E4<sub>in</sub> to T<sub>out</sub>)



NOTE - The values in the mask include the distortion power of an ideal encoder.

Figure I.8/G.712 – Signal-to-total distortion ratio as a function of input level for channels between a digital port and a 4-wire analogue port (T<sub>in</sub> to E4<sub>out</sub>)



Figure I.9/G.712 – Signal-to-total distortion ratio as a function of input level for channels between a 2-wire analogue port and a digital port (E2<sub>in</sub> to T<sub>out</sub>)



NOTE - The values in the mask include the distortion power of an ideal encoder.

Figure I.10/G.712 – Signal-to-total distortion ratio as a function of input level for channels between a digital port and a 2-wire analogue port (T<sub>in</sub> to E2<sub>out</sub>)

#### APPENDIX II

#### Method of derivation of the signal-to-total distortion ratio for the A-law

The signal-to-quantizing distortion ratio produced by PCM systems can be obtained analytically in a number of different ways. The method adopted here is a special case of a more general analysis which enables the calculated results to be compared directly with those obtained by practical measurements of the systems.

The compression characteristic of the system is assumed to be "ideal", i.e. to meet precisely the theoretical segmented law, with the system a.c. zero coincident with the centre decision amplitude. The input signal is assumed to be symmetrical about a.c. zero, and to have a Gaussian distribution of instantaneous amplitudes. For a given input of variance  $\sigma_v^2$ , the total output variance may be determined as  $\sigma_u^2$  and the variance of the signal content in the output, by linear regression, as  $m^2 \sigma_v^2$  where *m* is the slope of the regression line of output on input.

The variance of the distortion components is then  $\sigma_{\varepsilon}^2 = \sigma_u^2 - m^2 \sigma_v^2$ , and the signal-to-quantizing distortion ratio in dB is:

$$10\log_{10}\frac{m^2 \sigma_v^2}{\sigma_{\varepsilon}^2}$$

The limits of Figure I.5, which refer to *total* distortion, have been derived from the theoretical values of signal-to-*quantizing* distortion for A-law coding by subtracting 4.5 dB. In this way, practical imperfections of codecs, as well as a certain amount of noise, are taken into account. (Actually, the subtraction of 4.5 dB was applied to the break-points of the tolerance scheme in Figure I.5.)

# SERIES OF ITU-T RECOMMENDATIONS

- Series A Organization of the work of ITU-T
- Series B Means of expression: definitions, symbols, classification
- Series C General telecommunication statistics
- Series D General tariff principles
- Series E Overall network operation, telephone service, service operation and human factors
- Series F Non-telephone telecommunication services
- Series G Transmission systems and media, digital systems and networks
- Series H Audiovisual and multimedia systems
- Series I Integrated services digital network
- Series J Cable networks and transmission of television, sound programme and other multimedia signals
- Series K Protection against interference
- Series L Construction, installation and protection of cables and other elements of outside plant
- Series M TMN and network maintenance: international transmission systems, telephone circuits, telegraphy, facsimile and leased circuits
- Series N Maintenance: international sound programme and television transmission circuits
- Series O Specifications of measuring equipment
- Series P Telephone transmission quality, telephone installations, local line networks
- Series Q Switching and signalling
- Series R Telegraph transmission
- Series S Telegraph services terminal equipment
- Series T Terminals for telematic services
- Series U Telegraph switching
- Series V Data communication over the telephone network
- Series X Data networks and open system communications
- Series Y Global information infrastructure and Internet protocol aspects
- Series Z Languages and general software aspects for telecommunication systems